

# **SUCOTEC** HIGH-QUALITY CVD COATING EQUIPMENT



## **CVD – FOR PRODUCTION AND R&D** High-guality CVD coating equipment from Oerlikon Balzers

The SUCOTEC kila, mega and giga series are the new generation of high-quality CVD systems from Oerlikon Balzers. In use around the world, these systems have proven their outstanding performance, flexibility and reliability for nanolayers, multilayers and newly developed coatings in full production conditions.

The most modern Software CoatControl offers fully automatic process control, including intelligent subroutines to manage batch processing in any situation. It can multiply recipe blocks, run step sequences several hundred times for multilayers and back up recipes and status in a separate database. Customers can access PLC (Progammable Logic Controller) codes to

troubleshoot hardware and software, and a safety PLC (according to EN ISO 13849-1:2008) monitors all production-relevant valves and sensors to ensure the safety of the coating system.

Oerlikon Balzers supplies recipes for all SUCOTEC coating equipment that meet the demands of leading tool producers for cemented carbides, steel and other substrates. The superior quality of Oerlikon Balzers' coating systems and our outstanding commitment to our customers cover everything from adaptation to specific customer requirements in the early system development phase to our first-class after-sales service.

# **OERLIKON BALZERS' SUCOTEC EQUIPMENT** Welcome to the next level of CVD coating!

Accurate process parameters in SUCOTEC CVD systems enable high-performance coatings. Oerlikon Balzers has engineered coating equipment for more than 70 years and is represented in many countries worldwide, including an excellent service and support network.



Dr. Manfred Biedermann (left), Head of Business Line Equipment, Oerlikon Balzers, and Werner Bürgin (right), CEO Sucotec AG

## Sucotec joined the **Oerlikon Balzers family**

The acquisition of Swiss-based Sucotec AG in early 2018 by Oerlikon Balzers, a leading global provider of high-tech surface solutions, has not only further enlarged the company's unique product and service portfolio; it also secures the future of an advanced CVD coating system technology that gives customers the perfect surface solution for specific applications. Sucotec's coating systems will in future be based on Oerlikon Balzers' renowned R&D and engineering expertise, and will together continuously accelerate the development of CVD coating systems and offer a first-class global after-sales service.



You profit from a proven benchmark product backed by Oerlikon Balzers' first-class global customer service and support.

The former Sucotec AG has supplied marketleading CVD coating equipment and has many years of experience in building these systems. The following features and benefits make a SUCOTEC CVD coating system the right long-term choice:

# THE OERLIKON BALZERS SUCOTEC CVD EQUIPMENT FOR THE TOOLING INDUSTRY

Sizes for all needs



Capacity: example of C12 inserts (12.7 mm inserts, 10 mm bores, 25 mm outer rings)

# **Standard Equipment**

The coating process in all SUCOTEC CVD systems is carried out at pressures of 40mbar to 800mbar abs. and temperatures in the range of 700 °C up to 1030 °C. All specified components are industrially proofed and match with highest expectations.

All heated tubings and valves are insulated with prefabricated materials for best efficiency, avoiding of skin irritation and saving a lot of time for mounting.

## Coatings

Typical coatings which can be deposited with the basic configuration: TiN, TiC, TiCN, MT-TiCN, TiCNO, a/k Al<sub>2</sub>0<sub>3</sub>

Gases: Ar, H <sub>2</sub> , N <sub>2</sub> , HCl, CH <sub>4</sub> , H <sub>2</sub> S, CO <sub>2</sub> , CO	>	up to 25 Mass Flow Controller possible
Liquids: TiCl <sub>4</sub> , CH <sub>3</sub> CN	>	2 Coriolis
Solids: AICl <sub>3</sub>	>	1 Metal Chlorinator

## Graphite parts

- Standard rotating gas distribution
- Trays with 10mm holes and 25mm rings, or tailored to customer needs
- Preheating chamber

## Software "CoatControl"

- State-of-the-art safety PLC and access secure •
- Fully automated and easy to handle ٠
- Trend recording of all components used (pressures, temperatures, gas flows, valve position) •
- . Calculation of the quantities of gases, liquids and solids used in the recipe
- Batch oriented data acquisition ٠

# **Options**

The extensibility of all SUCOTEC systems allows additional gases and precursors which means they are well prepared for future developments and trends.

Coatings	Need
Nano columnar TiCN, TiSiN, TiSiCN	<b>&gt;</b> A
TiAIN and TiAICN (fcc or mixed fcc/h with high Al content), TiAICNO	<b>&gt;</b> s
HfN, ZrN, ZrN, ZrCN, ZrBCN, ZrO2, HrZrN, TaC, TaN	> N
Cr2O3, CrCx, Vox	> Ir
TiCN, TiB <sub>2</sub>	> в

## Graphite parts

- Special rotating gas distribution
- Static gas distribution
- Different tray geometries and ring heights, tailored to customer needs •
- Different gas preheating systems

## Software "CoatControl"

- Integration of customer safety devices into the SUCOTEC system
- MFM (Mass Flow Meter)

## Auxiliary equipment

- Low-maintenance process neutralisation system with 2 containers and automatic switch-over
- High-safety service neutralisation system
- State of the art semi-automatic cold trap cleaning system ٠
- Automated reactor brushing centre for optimal inside cleaning to reduce peeling of particles
- Integrated traversing hoist ٠
- Various vacuum pumping systems for extended parameter windows





Graphite parts

Cold trap system

In general, the SUCOTEC systems are not limited to the following options.

## ded options

Ar, C2H6, C2H4, SiCl4

NH<sub>3</sub>, Ar, N<sub>2</sub>

Special gas inlet, gas heating and gas distribution

Metal chlorinator for temperatures <450°C

Inner metal chlorinator for temperatures in the range of 700 - 1000 °C

BCl₃, Ar





Reactor brushing center

# **Software**

## Access secure and most modern software "CoatControl"

- The control system "CoatControl" offers remarkable capability for further development
- Fully automated •
- Possibility to multiply recipe blocks •
- Run step sequences of many 100 times for multi • layers
- Easy handling ٠
- Recipes and status stored in separate data base •



Plenty of possibilities for further developments





Second screen



Built-in PC with screen



Visualisation

## **Dimensions** Example for installation of SUCOTEC giga



# **PARTNERSHIP & SERVICES**

## **After Sales**

- Technical support and advice via telephone, the service hotline and e-mail
- Remote diagnostics and control for even faster troubleshooting
- Professional on-site support for installations, upgrades, repairs and maintenance tasks
- Engineer dispatch within 24 hours •
- Service agreements
- New and second hand parts, as well as consumables
- Upgrades, including the latest technologies and coatings
- Standard and customer-specific graphite parts

Our After Sales bases are located in Europe, America and Asia. From these locations, we provide you with services and products. Our service and application engineers worldwide help you keep your equipment up and running. Furthermore our parts warehouses located in Germany, the USA, Japan and China are committed to maintaining the productivity of your equipment.

# Consistently Convincing

Our global After Sales team is committed to providing consistent, expert support around the world.

## **Creating your individual portfolio**

We offer joint developments to create your individual coating for your specific application. Make your products stand out from the competition.



# **BENEFIT FROM OUR GLOBAL EQUIPMENT SALES AND AFTER SALES ORGANISATION**



### **Headquarters**

Oerlikon Balzers Coating AG Balzers Technology & Service Centre Iramali 18 9496 Balzers Liechtenstein T: +423 388 7500 F: +423 388 5419 E: info.balzers@oerlikon.com www.oerlikon.com/balzers

## USA

Oerlikon Balzers Coating USA Inc. 6000 North Bailey Avenue Suite 3 Amherst, NY 14226 USA T: +1 716 799 06 25 F: +1 716 639 39 38 E: info.balzers.us@oerlikon.com

### Germany

Oerlikon Balzers Coating Germany GmbH Am Böttcherberg 30–38 51427 Bergisch Gladbach Germany T: +49 2204 299-192 F: +49 2204 299-266 E: info.balzers.de@oerlikon.com

## India

Oerlikon Balzers Coating India Pvt. Ltd. EL-22, J Block, M.I.D.C., Bhosari 411026 Pune, Maharashtra India T: +91 20 306 16 000 F: +91 20 271 21 571 E: info.balzers.in@oerlikon.com

#### China

Oerlikon Balzers Coating (Suzhou) Co., Ltd No.9 Chang Yang Street Suzhou Industry Park Jiangsu Province Suzhou 215024 China T: +86 512 68835172 F: +86 512 68835327 E: info.balzers.cn@oerlikon.com

#### Japan

Oerlikon Nihon Balzers Coating Co., Ltd. 7-2-2 Shinomiya, Hiratsuka-City Kanagawa Pref. 254-0014 Japan T: +81 463 54 83 02 F: +81 463 54 22 19 E: info.balzers.jp@oerlikon.com

